



TI-84 Plus Silver Edition Faceplate Replacement

This guide will show you how to replace the face plate for the TI-84 Plus Silver Edition.

Written By: Agustin




INTRODUCTION

This guide shows you how to replace the face plate of the TI-84 Plus Silver Edition. The face place is the plastic that covers the gaps in between the keys and is below the screen.

Step 1 — Faceplate



- Insert your index finger in the open slot below the keys.


 Be careful to not bend the plate too much because it is very thin and might break.

- Apply a firm upward force until the bottom two tabs located near the bottom of the plate come off.

Step 2



- Grab the face plate on each side near the middle and apply a gentle upward force on each side until the middle tabs come off.

 A tab is located in the center of the face plate. If it is still attached, then continue to apply a gentle upward force until the center tab comes off.

- Lift the face plate upward until the top three tabs come off and the face plate is completely detached.

To reassemble your device, follow these instructions in reverse order.